

Toucan Touchscreen Gauge and CAL Selection Unit

User Guide (Syvecs/Life Racing) V1.84

For Toucan Firmware Version 1.84 and above

Disclaimer

Although every care is taken with the design of this product, JT Innovations Ltd. can in no way be held responsible for any consequential damage resulting from the use of Toucan in your vehicle.

Always operate your vehicle safely and do not allow yourself to be distracted by your Toucan display while driving. Minimise the amount of time you spend viewing the screen. Do not access any function requiring prolonged use of the menus whilst driving.

www.JTi.uk.com **support@JTi.uk.com**

JT Innovations Ltd
Unit 23
Tradecroft Ind. Estate
Portland
Dorset
DT5 2LN
UK
+44 (0) 1305 534535

© JT Innovations Ltd. 2019

Contents

Toucan Touchscreen Gauge and CAL Selection Unit 1

User Guide (Syvecs/Life Racing) V1.84 ... 1

Introduction 3

Installation 3

- Before You Start 3
- Installation 3
  - Connectors 3
  - Power 4
  - CAL Switch 4
  - RJ25 Data Connector 5
  - Multiway Connector 5
  - In-vehicle Mounting 6
- Initial Toucan Configuration 6
  - CAL switch configuration 6
  - Doesn't work? 7

Menus and Operation 8

- Gauge Screens 8
- Settings Menu 9
- Setup Menu 9
- Gauge Layout 10
- CAL Selection Menu 10
- Traction Control Selection Menu 10
  - Editing CAL Text 11
- CAL Voltage Adjustment 11
- CAL PIN Protection 12
- Alarm Configuration 13
  - Available Alarms 14
- Shiftlight Configuration 15
  - "More" Menus 16

CANbus/Custom RS232 17

- CANbus Termination 17
- Syvecs CAN bus configuration. 17
  - Datastream Configuration - S6/S8/S12, or S7+ using CAN2 17
  - CANbus Doesn't Work? 18

Advanced CAN configuration 19

- Frame/Slot Assignments (except S7I) 19
  - Turning Parameters Off 20
  - Extended Gauge Set. 20
  - Status Indicators 20
- Enable CAN Control 21
  - All ECUs except: S8; S7I; S7+ using CAN1 21
  - S7+ using CAN2, or S8 22

Keypad 22

Sensor Alarms 23

Firmware Updates 23

Technical 24

Glossary 24

Introduction

Thank you for purchasing a Toucan display. We hope it will be easy to install and configure, and suggest that you read this guide before you start.

Installation

Before You Start

Please check the box contents to ensure nothing is missing. You should have:

toucan Unit



Cable Harness




Mount (one of the following)



Installation

Connectors



Multiway	Connects to Toucan unit
RJ25	Data connection to Syvecs
BLACK	Power Ground
YELLOW	Permanent +12V
RED	Switched +12V
ORANGE	Lighting circuit
GREY	CAL Switch

ENSURE THE CAR BATTERY IS DISCONNECTED BEFORE ATTEMPTING TO INSTALL YOUR TOUCAN DISPLAY UNIT

IF IN DOUBT, PLEASE CONSULT A QUALIFIED AUTOMOTIVE ELECTRICIAN

Power

Each power feed has an inline fuse holder pre-fitted with a 1 amp 20mm glass fuse.

Ensure a good ground connection is provided to the BLACK wire.

To allow Toucan to power up quickly, it is recommended that a connection to both a permanent and switched (i.e. only live when the ignition is on) vehicle battery feed are made. When the ignition is off, Toucan will consume about 40 milliamps from the permanent connection – a typical, healthy, 40 amp-hour vehicle battery will last over a month before being run completely flat by Toucan: but it's your choice.

If you decide not to connect the YELLOW permanent +12 Volt, please make sure it is wired along with the RED connection to the switched ignition feed; otherwise Toucan may not start up when you turn on the ignition.


Toucan will take about 6 seconds to start if the permanent +12 Volt feed is not connected compared to less than a second when the permanent connection is made.


A connection to the vehicle lighting circuit may be made using the ORANGE connector – this will allow the Toucan unit to automatically dim when the vehicle lights are turned on. If not required, please insulate the unused wire to prevent damage to the unit or vehicle.

CAL Switch

The long GREY wire may be connected to the Syvecs CAL switch input to allow you to use Toucan to select the required calibration. V1.30 onwards Toucan firmware supports CAL control via CAN bus, so this grey wire can either be ignored (please make sure the bare end is insulated) or used as a traction control (or other) selection switch – see later.

The CAL switch for Subaru S6PnP ECUs is often wired to the green "test" connector located above the pedal box, near the steering column as shown below/left.





One of these two connectors is simply a ground connection: for "newage" vehicles (MY01 onwards) it is the female/receptacle connector that you need to connect to, as shown above/right. For "classic" vehicles, MY00 and earlier, it is usually the male connector – but sometimes it can be the black connectors: it is best to check with your mapper/fitter if you're not sure.

CAL switches for S6GP, S7 and S8 ECUs are usually wired directly to the ECU connector or loom adapter to an "AR" input, but check your own Syvecs installation and wiring schedule to be sure.

RJ25 Data Connector

S6PnP ECUs are provided with an RJ25 socket on the front edge of the ECU, adjacent to the Ethernet connector. Plug Toucan's RJ25 connector directly in to this socket. Make sure you do not connect it to the larger Ethernet connector as Toucan will not work – the usual symptom of this is that Toucan enters a self-test routine.



Syvecs S6PnP RJ25

S6GP, S6plus, S7 and S8 ECUs are not provided with a mating connector, so the RJ25 should be cut off and the wires connected as follows[1]. Make sure any unused wires are separated and individually insulated – shorting the RS232 pins will also put Toucan into its self-test mode.

RJ11	Cable Core	Syvecs Function	S6 Pin	S6+ S6I S7I Pin	S7+ Pin	S8 Pin
Pin 1	Blue *or* green	RS232 RX	55	B21	B21	48
Pin 2	Red *or* green/white	RS232 TX	56	B22	B22	21
Pin 4	White *or* brown	CAN HI	53	C9	C9 or B3[2]	82
Pin 5	Black *or* brown/white	CAN LO	54	C8	C8 or B2[2]	81

Multiway Connector

This connects to the rear of the Toucan unit. Note that it has a latching tab that must be depressed before the connector and cable can be detached.

The connector is intended to allow occasional removal of the unit from the car to allow, for example, firmware updates to be applied.

When detaching the unit, take care not to put unnecessary strain on the wires otherwise they may be damaged.

[1] Note: some cables supplied have a different colour coding. Pin 1 (RS232 RX) is brown; Pin 2 (RS232 TX) is green; Pin 4 (CAN HI) is blue; Pin 5 (CAN LO) is violet.

[2] See later for choice of CAN1 or CAN2 on S7+

In-vehicle Mounting

Toucan uses the Herbert Richter™ 4-prong mount system, which provides a secure mount when in the vehicle, but easy removal should it be required.

Initial Toucan Configuration

Having checked the installation of your Toucan, ensuring all connectors are fully home and especially that the power wiring is correct, reconnect the vehicle battery and turn on the ignition, ***but do not start the engine at this time***. After a few seconds, Toucan should power up and display the main gauge screen.

CAL switch configuration

If Toucan is being used to select calibrations via the grey wire rather than CANbus (see later), it is necessary to check that the voltage thresholds configured in the Syvecs ECU match those of your Toucan. Toucan supports 8 or 12 CAL positions. Analogue rotary CAL switches vary and your mapper may have adjusted the Syvecs values to match your specific switch. These are typical Syvecs threshold values:

8 CAL POSITIONS		
CAL	Syvecs threshold	Toucan Voltage
1	<0.36V	0.00V
2	>0.36V, <1.07V	0.70V
3	>1.07V, < 1.68V	1.40V
4	>1.68V, < 2.19V	1.95V
5	>2.19V, <2.79V	2.50V
6	>2.79V, <3.20V	3.00V
7	>3.20V, <3.61V	3.40V
8	>3.61V	4.00V

12 CAL POSITIONS		
CAL	Syvecs threshold	Toucan Voltage
1	<0.42V	0.00V
2	>0.42V, < 0.83V	0.60V
3	>0.83V, < 1.25V	1.00V
4	>1.25V, < 1.67V	1.40V
5	>1.67V, < 2.08V	1.85V
6	>2.08V, < 2.50V	2.30V
7	>2.50V, < 2.92V	2.70V
8	>2.92V, < 3.33V	3.20V
9	>3.33V, < 3.75V	3.50V
10	>3.75V, < 4.17V	3.90V
11	>4.17V, < 4.58V	4.30V
12	>4.58V	4.80V

To ensure Toucan and your Syvecs match, you can either alter the voltages in the Toucan unit, or alter the Syvecs calibration to match Toucan: in either case you will need to examine the Syvecs calibration. If you are not confident to do this, please contact your mapper, or contact technical support at JT Innovations for assistance.



Note that switching Toucan between 8 and 12 CAL positions will cause the voltages to default to the values in the tables above.

See the basic operation guide for how to adjust the CAL voltage output of Toucan.



Once the CAL voltages have been set, you can start the engine and begin to explore the gauge and other options available in your Toucan unit.

Doesn't work?

- Double check installation, especially the data connection to the Syvecs unit: is it plugged in to the Ethernet connection by mistake?
- Remove the cable from Toucan and re-attach a few seconds later – this will give the unit a reset.
- By default, Toucan connects using CANbus data. The Syvecs ECU may not have been configured to transmit CAN data, or the datastream may not be configured correctly. Try changing Toucan to use RS232 STACK or the Syvecs custom protocol. This is described in the basic operation guide – the setting is in the "MORE" menus.
- Contact technical support at JT Innovations for assistance.


Menus and Operation

Gauge Screens

Touch here to change current calibration. Label shown is the first 5 characters of the text entered.

Touch here to go to next gauge page

Touch here to go to previous gauge page



Shows which gauge screen is showing: A, B, C or D.

Launch Control status

- Red - OFF
- Yellow – armed, not active
- Green – active

Shows current Traction Control CAL. Touch to edit the names for each TC CAL and, if enabled, change the TC CAL. Labell shown here is the first FIVE characters off the entered text

Touch the centre of any gauge to display the full screen version and then cycle through all gauges or reset the peak marker.

Press and hold any gauge to display the most recently shown large gauge.

Return to the main gauge screen by touching the centre of the large gauge.

Touch here to enter SETTINGS menus

Shows Knock ignition retard has exceeded set value on any 1 or more cylinders (CANbus only). Also shows sensor alarms and limp/cut mode.

Touch to show knock, limp mode or sensor alarm full screen “gauge”.

AntiLag status

- Not present – not active
- Yellow – start CAL
- Green – active
- Red - shutdown

Four gauge screens are available with complete flexibility of which gauge is displayed where. This can be configured via the Gauge Select pages, accessible via the “Gauge Setup” button.

Only readings from sensors that are actually connected to the Syvecs ECU and configured correctly will be displayed.

Large Gauges

Goes to parameter list view.



Touch here to return to main gauge screen.



Touch here to mute an active alarm. Will be automatically unmuted when the alarm next clears

Resets the peak marker.

Settings Menu



Touch here to select full brightness

Touch here dim display to night brightness. Touch and hold to display a dimmed screen with no gauge activity, useful when the screen could be distracting.

Touch here to mute or unmute audible alarms.

Touch here to change current calibration

Touch here to return to gauge screen

Touch here to enter SETUP menus

If the "illumination" wire has been wired to the vehicle's lighting circuit, the manual day and night buttons will temporarily override the brightness as controlled from the vehicle.

Setup Menu



Touch here to adjust night brightness level

Touch here to adjust CAL voltages

Touch here to choose gauge layout and colour scheme

Touch here to configure alarms.


Touch here for "More" menus

Touch here to return to settings menu

Gauge Layout

This is accessed via the Gauge Setup button, and then “Gauge Select”.





Touch here to select which of the 4 pages to setup

Gauge name is shown

A unique “CAL Override” button may be placed here only, on one or more pages.

See “Advanced CAN configuration”

Touch the gauge that you wish to change. A 3 letter mnemonic describes the current gauge selected for each position

Touch here cycle between the next and previous gauges in the list



The two smallest gauge positions can be used for generic status indicators on one or more pages. See “Advanced CAN configuration.

CAL Selection Menu

First 5 characters of this text used on main gauge screen as label.



User Text describing this calibration

Touch here to edit the User Text


Next and previous buttons to select a different CAL

Touch here to return to previous menu

Traction Control Selection Menu


This is identical in operation to the CAL adjust function.

Editing CAL Text



Note that the first five characters of the CAL text is used on the main gauge screen as the label displayed and, likewise, if TC selection is available, the first 5 characters of the TC text will be displayed on the main gauge screen.

CAL Voltage Adjustment



Toucan supports 8 or 12 CAL positions which can be set via the “More” menus.

Note that switching Toucan between 8 and 12 CAL positions will cause the voltages to reset to default values.

CAL PIN Protection.

If enabled via the “more” menus, Toucan can be set to prevent the current CAL being changed unless you enter a 4 digit PIN. This can be useful if you have a “valet” CAL (with reduced rpm limit for example) and/or an anti-theft CAL. You can also set PIN protection to *only* apply to the last CAL (i.e. CAL 8 or 12), *only* to the first CAL or to *both* the first and last CAL.

There are a few things to be aware of if you choose to use this option:

- The default PIN is 0000 and it is recommended that you change this to something else.
- Once PIN protection is enabled, the (correct) PIN will need to be entered before you can change the PIN, or to disable PIN protection again.
- If the PIN is entered incorrectly 3 times, PIN entry will be prevented for the next 10 minutes. Note that this 10 minute timeout will be reset if power is removed from the unit.
- In the event that Toucan is disconnected from the Syvecs ECU, the ECU will, in most cases default to the highest numbered CAL position available in the ECU – usually 8 or 12 - (although this can be CAL 1 if a Syvecs input with no pullup resistor is used). It is generally recommended that the valet or anti-theft CAL is in position 8 or 12, or the PIN protect first CAL function (or first *and* last) is used.
- In the event that you forget the PIN it can be reset using a PC programme, connecting to Toucan via USB. This programme is available from the JT Innovations website, or contact technical support for assistance.



Alarm Configuration

The Alarms configuration menu allows you to determine which parameters will cause alarm events. A setting allows the audible alarm to be muted if the engine is not running.

An alarm event will:

- Cause an audible warning, unless Toucan is muted
- Cause the bezel of the relevant gauge to change to a flashing orange
- If enabled, cause the relevant gauge to be displayed full screen.
- Each large gauge has a “mute” button that temporarily mutes the alarm until either it clears and re-occurs; or you unmute it; or Toucan is repowered.

In addition, there is a low oil temperature warning that can be enabled. This will not sound the audible alarm, but will display a non-flashing orange bezel until the oil temperature exceeds the configured temperature. Obviously this function only works if an oil temperature sensor is connected to your ECU.


Available Alarms

- ACT. Any value in range, in 1°C steps. Alarm triggered if alarm value is exceeded. Default 50C.
- Battery voltage. Any value in range in 0.25V steps. Alarm triggered if current value is below alarm threshold. Default 11.5V
- Boost. Any value from 0 to max, in 0.05 bar increments. Alarm triggered if alarm value is exceeded. Default 1.5bar.
- Coolant temperature. Any value in range in 1°C steps. Alarm triggered if alarm value is exceeded. Default 95C.
- Exhaust Temperature (EGT1 and EGT2). Any value in range in 10°C steps. Alarm triggered if current value is above alarm threshold. Default 850C.
- Fuel Level Low. 0-100% in 1% increments. Alarm is triggered if current level is below the alarm value, default 10%.
- Fuel Pressure. Any value in range in 0.1bar steps. Alarm triggered if current value is below alarm threshold. Default 2 bar.
- Fuel Temperature. Any value in range in 1°C steps. Alarm triggered if current value is above alarm threshold. Default 70C.
- Injector Duty Cycle. Any value up to 100% in 1% steps, default 85%. Alarm triggered if injector duty cycle exceeds the alarm threshold.
- Knock. Any value in range 0-20 degrees of ignition retard in 0.5° steps. Default 5° (looks at all engine cylinders).
- Lambda 1 and Lambda 2. Any value in range, in 0.01 steps. Alarm triggered if alarm value is exceeded. Default 1.05.
- "Lean Lambda". Alarm is triggered if lambda exceeds set value AND RPM is above set value AND Boost exceeds set value.
- Limp/Trip. Enables an alarm if Syvecs enters Engine Limp or Trip mode.
- MAP. Any value from 1.0 to max, in 0.05 bar increments. Alarm is triggered if alarm value is exceeded. Default 2.5bar
- Oil Pressure. Any value in range in 0.1bar steps. Alarm triggered if current value is below alarm threshold. Default 2 bar.
- Oil Temperature. Any value in range in 1°C steps. Alarm triggered if alarm value is exceeded. Default 120C.
- Oil Temperature Low. Any value in range in 1°C steps. Alarm triggered if current value is below alarm threshold. Default 70C.
- RPM. Any value in range 0-10,000 rpm in 100rpm steps. Alarm triggered if alarm value is exceeded. Default 7500.
- Sensor Alarms. If configured in the Syvecs ECU, sensor alarms will notified, displayed as minor, moderate or critical as per the Syvecs calibration
- TPS. Any value 0-100%, 5% steps. Alarm triggered if alarm value is exceeded. Default 50%.
- Wheel speed. Any value in range in 1mph or 1kph steps. Alarm triggered if alarm value is exceeded. Default 70mph/120km/h

Shiftlight Configuration

If a JT Innovations Shiftlight is connected to Toucan, the shift LEDs can be configured from the Toucan screen. This is accessed via the Shift Light Setup button on the Setup screen.





Choose the LED to configure

Required colour and brightness, and whether the LED should flash, for the selected LED

Flash mode for outer 2 LEDs if there is a Toucan Alarm triggered.

Select to allow modes to be configured for "all LEDs"

The selected LED will light up at the configured "ON" rpm then extinguish at the configured "OFF" rpm

"More" Menus

The more menus allow you to select

- Units used – Metric, Imperial or "USA" (which uses Imperial measurements for everything except Boost and MAP which are in kPa)
- Speed display – mph or kph
- Enable the keypad option
- Whether the large full screen gauge should be automatically displayed should the gauge start showing an alarm
- Whether changing the CAL should be PIN protected – either all of them, or just the first or the last CAL, or both first and last CALs.
- Change the CAL PIN
- Select Absolute or Relative Fuel Pressure (Relative only available if CAN bus or custom serial data selected).
- Enable/Disable the display of peak markers on gauges. Peaks are remembered until manually reset on the large gauge display.
- Enable/disable dynamic peak markers. Dynamic peak markers maintain the current peak and trough for just a few seconds and then drop back to the current reading. The hold period can be adjusted.
- Choose the ECU interface (STACK, CAN 1Mbit, CAN 500kbit, or Syvecs customer serial data)
- Choose between 8 or 12 CAL positions
- Configure the CAN bus frame/slot assignments (see Advanced CAN configuration)
- Choose CANbus modes for S7 ECUs
- Allow CAN bus control of CAL selection (see Advanced CAN configuration).
- Mute alarms if the engine is not running - useful if the vehicle is not being driven, but the ignition is switched on.
- Turn the audible touchscreen feedback beep on/off
- Determine which large gauges will be displayed when you cycle through them. This is useful to hide gauges when the appropriate gauge sensor hasn't been fitted.
- Display CAN termination on/off, software version, the current/actual CAL voltage, and the currently detected communications protocol.

CANbus/Custom RS232

Although you can connect to the Syvecs ECU using RS232 serial data using the "STACK" protocol, this limits functionality and is not generally recommended. It is best to ensure you use either the CANbus or Custom RS232 serial data options – the Custom serial data carries exactly the same information as is configured for CANbus and may be configured in the Syvecs to be active alongside CAN bus.

CANbus Termination

It will be necessary to enable the bus termination if Toucan is the last device on a CANbus network. By default the termination is switched off, but it may be enabled by sliding the small switch on the rear of the unit towards the 4-prong mounting plate. You may need to use a small screwdriver to access the switch through the rear cover.

You can confirm the status of the termination switch via the "more" menus.

Syvecs CAN bus configuration.

For S6, S8 and S12 variants, the CAN datastream needs to be set up as per the following section. If the ECU is an S7I, the datastream format is fixed and does not need configuring. Ensure the "S7I" checkbox is selected on "More" page 4.

If the ECU is an S7+, you can still use the fixed datastream from CAN1 but choose the S7I option on "More" page 4. Alternatively you can enable the S7+ option which:

- Uses the same datastream defaults as S6/S8/S12 as per the section below
- Transmits data to the S7+ using the "generic receive" functionality of the ECU. This is explained later

Datastream Configuration - S6/S8/S12, or S7+ using CAN2

To ensure that Toucan is able to receive CAN bus data or custom Serial data, the Syvecs ECU calibration must be changed to configure the necessary CANbus parameter, and for the datastream itself to be either CAN or Custom Serial.

If in doubt, consult your installer/mapper or JT Innovations technical support: but this is the basic procedure.

1. Download the Toucan CANbus calibration file from the JT Innovations website.
2. Ensure you have the latest Syvecs software and firmware by downloading it from the Syvecs forum, accessible through the Syvecs website
3. Run SCal and connect to your Syvecs ECU, to obtain a copy of the current configuration. Make sure you save a copy of this configuration to your computer before making any changes!
4. Now use the Import function in the File menu and select the Toucan CANbus calibration file you downloaded. This file has everything set to "invalid" except the datastream settings – no changes will be made to anything in your existing calibration except the necessary datastream settings.

5. This file selects CAN as the datastream format – if necessary or preferred, change the datastream option to echo CAN data on the ECU RS232 port.
6. You should now save this calibration on your computer for future reference.
7. If SCal is still connected to your vehicle's powered ECU, the changes will have been made "live" but you need to **Program** the calibration to the ECU from the **Device** menu. If you have made the changes offline, you will need to reconnect to the ECU and perform a "disk calibration" by opening the newly modified calibration after you have connected SCal to the ECU, and then performing the **Program** operation when prompted.

Finally, change Toucan to use CANbus or Syvecs Custom RS232 using the "more" menus.

Toucan should now be communicating with the Syvecs ECU using CANbus parameters.

CANbus Doesn't Work?



Please note that a small number of Syvecs units do not have a fully functioning CAN bus interface. If you find that Toucan stops displaying information once you switch to using CAN bus data, but does still work if you revert to STACK RS232, then change both Toucan and the ECU to use "Custom RS232" – all the data configured on the CAN datastream will then be transmitted on the RS232 interface instead. This option is only available in Syvecs version 1.25 onwards.


Advanced CAN configuration

Frame/Slot Assignments (except S7I)

Although the JT Innovations-supplied CAN datastream definitions are applicable in the majority of cases, there are occasions when it is not possible to use this. One example is when the Syvecs is installed in a vehicle that uses a CAN bridge module, which then needs CAN data in specific, incompatible slots.

On “More Page 4” you can access an editor to alter the Toucan CAN frame and slot assignments.

This is considered an Advanced option and should only be done if you are comfortable accessing the calibration in your Syvecs using SCal to determine the frame and slot assignments.



Turning Parameters Off

The frame/slot assignments can be used to turn off parameters by setting the frame to “0”. This is mostly useful in two specific instances:

1. Traction CAL. If the frame is set off, the “TC” icon will not appear on the main screen and the ability to name and select the traction CALs is hidden.
2. Turning off knock ignition retard assignments for any cylinders will make sure the knock value for those cylinders are not displayed, nor used for the overall knock alarm calculations.

Extended Gauge Set.

There is a duplicate set of gauges for: Gear, Air Temp, Coolant Temperature, Throttle, RPM, Oil Pressure and Oil Temperature. By default these parameters have their frame assignment set to 0, which hides and disables them. They can be “activated” by configuring valid frame and slot settings – these must match the setting of the ECU datastream – and they can then be chosen to be viewed on the main gauge screens etc.

These can be useful if, for example, two air temperature sensors are fitted, one before and one after the intercooler perhaps. They can also be used for any other parameter (e.g. transmission temperature) as long as the parameter scaling matches that of the gauge itself.

Status Indicators

Status indicators are available on any or all of the main gauge pages in the location of the two smallest gauges. By default, the CANbus frame assignments are set to frame 12 Slot 1 – if the ECU is set to transmit a status (such as aircon, or water injection, etc.) then status can be viewed. Status “0” will show as a red indicator, “1” as green, “2” as yellow and “3” as blue.

Enable CAN Control

CAN control can be enabled using the "TX CAN" check box on "More Page 4". This is not possible on S7I ECUs. Enabling this:

- Causes the selected CAL to be transmitted via CAN bus to the ECU. This frees up the CAL voltage input to the ECU and allows it to be used for another function.
- All ECUs except S7+: If the grey CAL wire from Toucan remains connected to the Syvecs ECU, it can be redeployed to either be used as a Traction Control CAL switch (or for any other function that can make use of an 8 or 12 position selection switch) or as a launch control on/off that will switch between 0V and 5V when the Launch Control icon on the main gauge screens is touched
- S7+ only: Allows launch control on/off via CANbus
- Enables the main gauge screen "ALS" button to turn ALS on/off (but only if the currently selected CAL actually has ALS enabled).
- Enables the CAL Override button (see Gauge Layout configuration, earlier). This transmits a CAN message to the Syvecs allowing a pre-determined CAL to be selected. This must be configured in the Syvecs ECU first.
- S7+ only: Allows TC maps to be changed via CANbus
- S7+ only: Allows launch control maps to be changed via CANbus

To use CAN control, Syvecs firmware V1.40 or later must be used, and the Syvecs calibration must be changed, as follows, using SCal:

All ECUs except: S8; S7I; S7+ using CAN1

- Under "Datastreams", then "Custom CAN", then "Bosch ABS M4-Kit": set "Receive Bosch ABS M4-Kit CAN frames" to "YES".
- For the CAL indication to work correctly, the latest CAN stream definitions need to be applied. The key parameter is Frame 11, Slot 2 which needs to be changed from "CalSwitch(U)" to "CalSelect(U)".
- Make absolutely sure that the original CAL input to the Syvecs is disabled or redeployed (via "IO Configuration") – as a TC switch or launch control input, for example.

Note that Toucan does not transmit all of the data the comprises the Bosch M4 ABS data set so, unless the vehicle is already transmitting these and the vehicle CAN bus is connected to the Syvecs, there will be errors reported due to the missing frames.

This is normal and is not a cause for concern.


S7+ using CAN2, or S8

Using CAN2 on the S7+, or either CAN on the S8

- Under “Datastreams”, then “Generic CAN receive”:
  - Set “Receive B Enable” to “YES” for “B01..B08”.
  - Set “Receive B Bus” to “CAN2” (for S7+) or (usually) “CAN1” for the S8
  - Check that “Receive B Identifier” for “B01..B08” is set to “0x644h” (the default)
- Under “IO Configuration” and “Pin Assignments” set, as required:
  - ALS Enable Switch to use “X:CAN RECEIVE B #01”
  - Launch Control Switch to use “X:CAN RECEIVE B #02”
  - Calibration Switch to use “X:CAN RECEIVE B #03”
  - ALS Select switch (or Traction Control Switch, as preferred) to “X:CAN RECEIVE B #04”
  - Calibration Override switch to “X:CAN RECEIVE B #05”
  - Launch Select switch to “X:CAN RECEIVE B #06”
- Check and if necessary edit the “Generic CAN Transmit” stream:
  - Frame 11 Slot 1 either “tcSelect” or “alsSelect” as required
  - Frame 11 Slot 2 is “calSelect”
  - Frame 11 Slot 3 is “launchRPM”

Keypad

A Keypad can be enabled via the “More” menus. A separate document is available from the JT Innovations website that explains how to configure the keypad.



Sensor Alarms

Syvecs firmware version 1.25 onwards allows sensor alarms to be configured, and for this information to be transmitted via CAN bus to Toucan. In essence, individual sensors can be configured to be ignored if they fail, or to generate a minor, moderate or critical alarm value. If this is configured in the calibration, Toucan alarms can be enabled to draw your attention to sensor failures. SCal will still be needed to determine which sensor has actually caused the alarm.

Your mapper can advise on the best configuration of sensor alarms for your specific vehicle, or contact JT Innovations technical support for advice.

Firmware Updates

Occasional firmware updates will be made available to add new features. These may be downloaded from the Downloads section of the JT Innovations website.

Updates are applied using a PC program (also available from the website) and a standard "mini" USB cable. Updates should be applied with the Toucan disconnected from the vehicle. It will be powered from the PC USB port, although the LCD will be shut down.

It is recommended that you register your Toucan with us on the website – that way we can keep you informed when firmware upgrades are available.

Technical

Data Interface	CAN 2.0B at 1Mbit/s or 500kbit/s with selectable termination, or RS232 .
Expansion Connector	RS232, CAN, Power Out and Ground. Allows connection of toucan expansion accessories.
Power	8-20V <200mA typ. <40mA in standby mode Connections to permanent, switched and illumination power, via 1A fused connections.
CAL Voltage	Adjustable via menus to match Syvecs configuration. Fail-safe monitoring of CAL voltage.
Memory	Non-volatile storage of all parameters
Firmware Updates	Via rear-panel USB connector, using PC programme.
Compliance	Directives: 2002/96/EC, 72/245/EC, EN50498:2010
Warranty	1 year
Dimensions	100x83x16mm
Weight	200g
Display	3.5" QVGA TFT, 320x240 pixels, 24 bit colour, with touchscreen
Processing system.	190MHz 32 bit ARM9, 8Mbytes Flash memory, 8Mbytes SDRAM.
Package contents	Toucan unit, power/data cable harness, mount, installation guide.
Available Gauges/Alarms	Air intake temperature; Battery Volts; Boost (2.5 bar and 3.5 bar); Exhaust Gas Temperature (2 channels); Fuel level; Fuel Pressure; Fuel Temperature; Current Gear; Injector Duty warning; Knock; Lambda (2xwideband channels, 1x narrowband); Lean Lambda warning; Engine limp/Cut mode; MAP; Oil Pressure; Oil Temperature; RPM; Sensor Error; Throttle Position; Coolant Temperature; Wheel Speed.

Glossary

Term	Description
ACT	Air Charge Temperature
CANbus	"Controller Area Network" bus – a serial interconnect common in vehicles.
ECT	Engine Coolant Temperature
EGT	Exhaust Gas Temperature
EOP	Engine Oil Pressure
EOT	Engine Oil Temperature
FP	Fuel Pressure
MAP	Manifold Absolute Pressure – the air pressure in the manifold, atmospheric pressure is 1bar, total vacuum is 0bar.
TPS	Throttle Position Sensor